



What is “latency” of a ship position?

The time interval between the time of the ship position (receiving antenna) and the time of receipt at EMSA



InArea monitoring



Wrong chronological sequence

